



THREE CHANNEL COUNTDOWN/UP TIMER



Operating Instructions

Product code:

806-301

INSTRUMENT OPERATION - Push and hold the timer belt clip and remove the battery cover. Insert the batteries, replace battery cover. This timer can be switched on by sliding the switch on the back of the unit from the OFF position to either the 12/24 Hr position, the timer will display '00 00' and the clock will need be to set.

CLOCK - Press and hold the CLOCK/TIMER button until you hear a beep and the time is seen to flash in the display. Press or hold the HR button to change the hours. Press or hold the MIN button for minutes and SEC button for seconds. Pressing the CLOCK/TIMER button will start the clock. The time can be set to 12 or 24 HR via the switch at the rear of the unit. When the unit is in clock mode, the clock is shown in the top of the display. Pressing the START/STOP button will start the count up timer in the middle and bottom display, middle for milliseconds. Hour/minute/seconds display in the bottom display. To clear these readings, press the CLEAR button.

TIMER OPERATION - Press the CLOCK/TIMER button so that all three times are shown in the display. 'Press and hold the relevant TIMER button (TIMER 1/2/3) until you hear a beep and the time is seen to flash in the display Press or hold the HR button to change the hours. Repeat for minutes and seconds. Pressing the relevant TIMER button (TIMER 1/2/3) will set the time, press again to start/stop the countdown for individual times set. Once the set time has elapsed, the unit will flash and sound continuously for one minute. The unit will start and continue unless reset to count up, at the same time TIME'S UP will be shown in the display. Pressing the START/STOP button will pause the time, and pressing the CLEAR button will set the display to 0:00 00. If you are in the clock mode and a time has been set and the relevant timer is counting down then the TIMER 1/2/3 will flash in the top/middle or bottom display. Press the CLOCK/TIMER to return to the timer setting. You can set all three timers to go at once by setting the time required and pressing the START/STOP button.

GUARANTEE - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. This guarantee does not apply to sensors/probes, where a six-month period is offered. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etiltd.com/terms. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.

Supplied by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltd.com · etiltd.com

806-301/31.12.19